

# DATASTORM CONTROL CABLE LENGTHS

The DataStorm receives all its commands and power from the Control Cable. This cable can be prone to degradation depending on the length. After a certain length is reached, a larger gauge of wire must be used to ensure proper communication. Below is a chart to aptly identify which cable is best for your installation:

## *DataStorm<sup>2</sup>* F1 .74 METER SYSTEM

30' 22 Gauge

---

50' 22 Gauge

---

75' 18 Gauge

---

..... CERTIFIED MAX DISTANCE\* .....

150' 16 Gauge

---

250' 14 Gauge

---



## *DataStorm<sup>2</sup>* F3 1.2 METER SYSTEM

30' 18 Gauge

---

50' 18 Gauge

---

..... CERTIFIED MAX DISTANCE\* .....

75' 16 Gauge

---

150' 12 Gauge

---

250' 10 Gauge

---



\* Please call MotoSAT for information on purchasing and using a Control Cable beyond the certified distances. 1-800-247-7486